



26	Knob	B10-PLC-1208-00	Red and Yellow and white	
25	Self-attacking screw	SCR-SIR-3512-2S	-	
24	Gasket (B4)	WSH-P10-1245-S1	-	
23	Power cord	PWC-9VC-5013-2C	1.2m, white cp2	
22	Self-attacking screw	SCR-SIR-3010-3M	Switch screw	
21	Piano switch	B10-MET-1520-20	six keys and four speeds	
20	Five hole bracket	B10-PLC-1811-01	Gray	
19	Guarding board	B10-PLC-1812-00	Offwhite guarding board	
18	Gum feet	B10-PLC-0018-00	Rubber, black T style	
17	Self-attacking screw	SCR-SIR-3512-2S	Bottom screw	
16	Bottom (Blank)	B10-PLC-1812-00	Gray without words	
15	Motor	B10-MTR-7020-25	Triangle four speed	
14	Body	B10-PLC-1803-00	Off white	
13	Small sealing ring	B10-PLC-0916-00	Umbrellatype white	
12	Shockproof ring	B10-PLC-0919-00	Rubber	
11	Double bracket screw	SCR-SIR-5012-4M	Mashine bolt	
10	Plastic gear	B10-PLC-4014-00	six gears POM+black kind	
9	Rubber gear	B10-PLC-0017-00	Rubber Black	
8	small gasket	WSH-B710050-M2	-	
7	Bearing	B10-MET-B722-00	Powder metallurgy copper	1
6	Base	B10-PLC-5807-00	Offwhite	1
5	Quateblade	B10-MET-W621-00	Optic axis	1
4	Big sealing ring	B10-PLC-0816-00	rubber,gray	1
3	Jar	B10-PLC-2T01-00	Transparent	1
2	Cover of jar	B10-PLC-3805-00	Off white	1
1	Handle of jar	B10-PLC-2T06-00	Transparent	1
NO.	PARTS. NAME	PARTS. NO	MATERIAL.	QTY