



D08	DOOR GASKET	1	C26	SWITCH CIRCUIT	1
D07	DOOR PANEL	1	S02	SCREW ST3*8PBHC	2
D06	DOOR SCREEN	1	C18	PCB ASS'Y	1
D05	DOOR INNER FILM	1	C08	BUTTON SPRING	1
D04	UPPER HINGE	1	C13	DOOR OPEN LEVER	1
D03	LATCH SPRING	1	C07	DOOR OPEN BUTTON	1
D02	LATCH	1	C05	MEMBRANE DECORATION	1
D01	DOOR FRAME ASS'Y	1	C01	CONTROL PANEL	1
D00	DOOR	1	C00	CONTROL PANEL ASS'Y	1
No.	Part Name	Qty.	No.	Part Name	Qty.

Model PM70744 & PM70745