


**PPG5505**  
EXPLODED VIEW  
PARTS LIST

NO.	Code	Part name	quantity
1	DJ180F-11100-AE	CRANKCASE	1
2	GB276-89-6206	BALL BEARING	2
3	DJ177F-11014-A	OIL SEAL	2
4	DJ188F-13201-A	ROCKER ASSY	2
5	DJ177F-15001-A	SHAFT, GOVERNOR ARM	1
6	DJ188F-15002-A	WASHER, GOVERNOR ARM SHAFT	1
7	DJ188F-15003-A	PIN, LOCK	1
8	DJ188F-11004-A	BOLT, DRAIN PLUG	2
9	DJ188F-11005-A	WASHER, DRAIN PLUG	2
10	DJ188F-18200-B	SWITCH ASSEMBLY, OIL LEVEL	1
11	GBT16674-B6-16	BOLT	2
12	DJ168F-11002-A	DOWEL, PIN, CASECOVER	2
13	DJ180F-12001-B	PISTON	1
14	DJ180F-12300-B	SCRAPER RING SET, PISTON	1
15	DJ177F-12200-AE	ROD ASSEMBLY, CONNECTING	1
16	DJ177F-12002-A	PIN, PISTON	1
17	DJ168F-12003-A	CLIP, PISTON	2
18	DJ177FD-11001-A	COVER ASSEMBLY, CRANKCASE	1
19	DJ168F-18300-A	AMPLIFIER	1
20	DJ177F-15100-A	GOVERNOR ASSEMBLY	1
21	DJ177F-11200-A	CYLINDER HEAD	1
22	DJ177F-13001-A	VALVE, IN	1
23	DJ177F-13002-A	VALVE EXHAUST	1
24	DJ188F-13010-A	RETURNER, INTAKE VALVE	1
25	DJ188F-13011-A	OIL SEAL, VALVE	1
26	DJ188F-13003-A	SPRING, VALVE	2
27	DJ188F-13004-A	SEAT, VALVE SPRING, IN	1
28	DJ188F-13005-A	SEAT, VALVE SPRING, EX	1
29	DJ188F-13300-A	PLATE, PUSH, ROD GUIDE	1
30	DJ188FD-11007-D	DIPSTICK	1
31	DJ188F-13006-A	ROTATOR	1
32	DJ177FD-14001-A	BOLT, STUD	2
33	DJ168F-14002-B	BOLT, STUD	2
34	DJ188F-14006-C	PACKING, EXHAUST	1
35	DJ180F-14009-A	EXHAUST PIPE	1
36	GBT93-LW-B	SPRING WASHER	2
37	GB6170-N-8	NUT	2
38	DJ188F-14100-BE	CARBURETOR ASSEMBLY	1
38.1	DJ188F-14106-A	FLOAT	1
38.2	DJ188F-14109-A	FUEL INJECTION NEEDLE	1
39	DJ188FD-14007-A	FUEL LINE	1
40	DJ168F-14008-A	CLIP, FUEL LINE	1
41	DJ168FD-14014-A	RUBBER, FUEL	1
42	DJ177F-15004-A	GOVERNOR ARM	1
43	DJ177F-15005-A	BOLT, GOVERNOR ARM	1
44	GB6177-N-6	NUT	3
45	DJ180F-12100-BE	CRANKSHAFT ASSEMBLY	1
46	DJ188F-13009-A	LIFTER, VALVE	2
47	DJ177F-11003-B	PACKING, CASECOVER	1
48	DJ177F-15007-A	SPRING, GOVERNOR	1
49	DJ177F-13100-AE	CAMSHAFT ASSEMBLY	1
50	GBT16674-B8-35	BOLT	5
51	GBT16674-B8-40	BOLT	2
52	DJ188F-11009-A	PIN, DOWEL	2
53	DJ180F-11010-C	GASKET, CYLINDER HEAD	1
54	GBT16674-B10-80	BOLT	4
55	DJ168F-18500-A	SPARK PULG	1
56	DJ177F-13008-A	ROD, PUSH	2
57	DJ177F-11012-A	SHROUD	1
58	GBT16674-B6-12	BOLT	9
59	DJ188F-11300-H	COVER COMP, CYLINDER HEAD	1
60	DJ188F-11011-A	PACKING, HEADCOVER	1
61	DJ188F-11015-A	LOCK BOLT	1
62	DJ177FD-15200-A	SHROUD ASSY, UPPER	1
63	DJ177F-16200-AE	FLYWHEEL ASSEMBLY	1
64	DJ177F-16002-A	FAN, RECOIL STARTER	1
65	DJ177F-16000-A	PULLEY, STARTER	1
66	DJ188F-16205-A	NUT	1
67	DJ188F-11017-A	RUBBER, STARTER ASSY	1
68	DJ188F-18100-C	IGNITION COIL ASSY	1
69	GBT16674-B6-25	BOLT	2
70	DJ177F-14003-B	PACKING, INTAKE	1
71	DJ177F-14004-A	INSULATOR, CARBURETOR	1
72	DJ177F-14005-B	PACKING, CARBURETOR	1
73	DJ168F-13202-A	BOLT	2
74	DJ188F-14027-A	SPACER, CARBURETOR	1
75	DJ177F-15006-A	ROD, GOVERNOR	1
76	DJ188F-15008-A	SPRING, THROTTL RETURN	1
77	5150096-147	RECOIL, STARTER ASSEMBLY	1
77.1	DJ188F-16130-B-147	STARTER COMP, RECOIL	1
77.2	DJ188F-16111-A	ROPE	1
77.3	DJ168F-16110-A	GRIP STARTER	1
78	DJ188F-11039-B	CLIP	2
79	DJ188FD-14200-A	AIR CLEANER ASSEMBLY	1
79.1	DJ188FD-14203-A	bottom cover, air cleaner	1
79.2	DJ188FD-14201-A	Element, Air cleaner	1
79.3	DJ188FD-14204-A	cover, air cleaner	1
79.4	DJ188FD-14202-A	BRACKET, ELEMENT	1
80	DJ188FD-11013-A	TUBE, BREATHER	1



**PPG5505**  
EXPLODED VIEW  
PARTS LIST

NO.	Code	Part name	quantity
1	8322052	motor assembly	1
1.1	DF5000H-33120-BJ	Rotator	1
1.2	DF5000H-33110-BJ-23602H	stator	1
1.3	DF3800H-33001-A	carbon brush comp	1
1.4	DF3800H-33002-B	grounding post comp	1
2	DF3800H-33005-A	motor stand	1
3	DF5000H-33021-A	Bolt M5×158	2
4	GB6170-N-5-H	Nut	2
5	GBT97-W-5	Flat Washer	2
6	GBT93-LW-5	Spring Washer	3
7	8110452-010	Frame	1
8	DF3800H-31201-A	Isolator A	2
9	DF3800H-31202-A	Isolator B	2
10	GB6170-N-8	Nut	4
11	8150022-147	FUEL TANK ASSY	1
11.1	DF2500H-14307-A	Fuel Filter	1
11.2	DF2500H-14306-A	fuel tank cap comp	1
12	DF2500H-14302-A	Fuel Cock	1
13	DF4950H-A-QQ-001E	Engine Assy	1
14	DF6500H-34216-A	grounding wire	1
15	DF6500H-11032-B	guard cover, crankcase	1
16	GBT820-B5-12	Crossing Screw	1
17	DF5000H-33003-A	Bolt	1
18	DF3800H-14024-A	Flat Washer	1
19	GB6177-N-12	Nut	2
20	DF5000H-33015-A	Bolt	4
21	GBT16674-B6-12	Bolt	4
22	GB6177-N-10	Nut	4
23	DF3800H-14205-A	Bracket, air cleaner	1
24	GB6177-N-6	Nut	2
25	DJ188FD-14010-C	Gasket, Exhaust Pipe	1
26	DF6500H-31017-K	Wheel	2
27	8150182	Muffler COMP	1
28	GBT93-LW-8	Spring Washer	2
29	GBT16674-B8-30	Bolt	2
30	DF3800H-14404-B	Muffler mounting bracket	1
31	GBT16674-B8-16	Bolt	8
32	7010087	panel comp	1
32.1	34203-004	Switch Assembly	1
32.2	34204-061	DOUBLE RECEPTACLE AMERICA	1
32.3	34204-060	TWIST LOCK OUTLETS L14-30R	1
32.4	34208-021	THERMAL PROTECTOR 20A	3
32.5	34208-022	THERMAL PROTECTOR 23A	1
32.6	34204-001	TWIST LOCK OUTLETS	1
33	DF2500H-34106-A	Washer	4
34	DJ168F-14008-A	Clip, fuel line	1
35	GBT16674-B8-45	Bolt	2
36	DF8000H-33011-D	Automatic Voltage Regulator	1
37	GBT16674-B5-16	Bolt	3
38	GBT16674-B5-12	Bolt	7
39	DF2500H-14024-A	Washer, Fuel Tank	4
40	92140-B6-25	Bolt	6
41	8190421-147	End Cover, Generator	1
42	DF2500H-31019-B	Cotter Pin	2
43	DF6500H-31058-A-010	Handle Assembly	2
44	DF6500H-31016-A	Rubber, handle	2
45	DF6500H-31073-A	Plug, handle	2
46	DF6500H-31020-A-010	Support, frame	2
47	DF9000H-31204-A	vibration isolation pad, square	2
48	GB6177-N-8	Nut	6
49	DF3000H-31018-A	Axle	2
50	DF6500H-31074-A	Bush, handle	4