



32	HL-PC-002UL-00]	Cord set	1				
31	SC-35.UL	S/S clip	1	Nylon			
30	SC-25D-R-023	Screw	1	S/S			
29	M4X10+Spring washer + flat washer	Rivet	4	Nickel-plate			
28	Φ3X8	Leg	3	Aluminium			
27	RC-10-018	Screw	3	PP			
26	ST4X10C	Base cover	2	Nickel-plate			
25	RC-8-017-04	Screw	1	08F			
24	ST3X8FT	Switch lever assembly	2	Nickel-plate			
23		Switch	1	Zinc plate			
22	RC-10-012	Control panel	1	PP			
21	RC-8002-02-01	Lampshade PC (orange)	1	PP			
20	RC-4-013	Lampshade PC (red)	1	PC/			
19	RC-4-013	Indicator assembly	1	PC/			
18	RC-10-122	Indicator clip	2	120KΩ/长130/100			
17	RC-8-A-02-05	Screw	1				
16	ST3X6FT	Outer housing	1	Nickel-plate			
15	RC-8-209	Handle	1	08F			
14	RC-8002-01-01	Screw	4	PP			
13	ST4X12FT	Screw	4	Nickel-plate			
12	ST4X8FT	Keep warm assembly	1	Nickel-plate			
11	RC-8-021	Middle housing	1	Silicon fiber			
10	RC-8-015	Screw	1	08F			
9	M4X8+Spring washer	Heating plate	3	Nickel-plate			
8	RC-8-016-120	Thermostat	1				
7	RC-10-019	Inner pot	1				
6	RC-8-008	Screw	1	Alloy aluminium			
5	M8X16	S/S pad	1	Aluminium			
4	SC-65-0N01-01-03	Silicon rim	1	S/S			
3	RC-10C-004	Glass lid	1	Silicon			
2	RC-8-003-6	Lid knob	1	Tempered glass			
1		PCPName	1	PP			