


NO.	SPARE PARTS	code
2	FRONT PANEL ASSEMBLY	3.1.1.40.0010
5	EVAPORATOR	1.03.56.633
6	EVAPORATOR FAN	1.01.11.175
9	LED BOX	3.7.09.510
10	TOP LED LIGHT	1.01.08.081
12	DIGITAL CONTROL BOARD	1.01.13.151
15	LED LIGHT	1.01.08.082
16	DOOR GASKET	1.02.61.851
17	LEFT DOOR	1.03.68.689
18	LEFT DOOR HANDLE	1.02.26.509
19		1.02.26.510
20	RIGHT DOOR	1.03.68.688
25	RACKS	1.03.95.10.235
30	RIGHT HINGE	1.03.79.161
31	CONDENSER	1.03.57.069
32	CONDENSER FAN	1.01.11.202
36	UNIVERSAL WHEEL	1.02.75.011
43	COMPRESSOR	6.03.01.369
46	POWER CORDS	1.01.01.252
47	LEFT HINGE	1.03.79.160
49	SENSOR WIRE	1.01.13.159
53	UPPER HINGE	1.03.79.159
54	SENSOR	1.01.13.158

**PRN165DX
PRN185DX**



1	CABINET	36	UNIVERSAL WHEEL
2	FRONT PANEL ASSEMBLY	37	HOLDER
3		38	SUPPORT PLATE
4		39	PANEL
5	EVAPORATOR	40	PANEL
6	EVAPORATOR FAN	41	WATER DRYER BOX
7	FAN COVER	42	SUPPORT PLATE
8	FAN PANEL	43	COMPRESSOR
9	LIGHT BOX	44	WATER DRYER
10	TOP LED LIGHT	45	COMPRESSOR COVER
11	LAMP SWITCH	46	POWER CORDS
12	DIGITAL CONTROL BOARD	47	LEFT HINGE
13	ELECTRICAL BOX	48	SUPPORTER
14	LED LIGHT COVER	49	SENSOR WIRE
15	LED LIGHT	50	INNER WIRE
16	LEFT DOOR GASKET	51	BRACKET
17	LEFT DOOR	52	RACKS HOLDER
18	LEFT DOOR DANDLE	53	UPPER HINGE
19	RIGHT DOOR GASKET	54	SCREW
20	RIGHT DOOR	55	SENSOR
21	RIGHT DOOR HANDLE		
22	LEFT LOCK PLATES		
23	RIGHT LOCK PLATES		
24			
25	RACKS		
26	DECORATION PANEL COVER		
27	DECORATION PANEL		
28	CENTER SILL		
29	BOTTOM COVER		
30	RIGHT HINGE		
31	CONDENSER		
32	CONDENSER FAN		
33	CAPACITOR		
34	COMPRESSOR PANEL		
35	SUPPORTER PANEL		