


NO.	SPARE PARTS	code	1% parts suggest
2	FRONT PANEL ASSEMBLY	3.1.1.40.0010	
4	TOP LED LIGHT	1.01.08.081	
5	UPPER HINGE	1.03.79.159	
7	EVAPORATOR	1.03.56.633	1
8	EVAPORATOR FAN	1.01.11.175	1
14	LED BOX	3.7.09.510	
15	DIGITAL CONTROL BOARD	1.01.13.151	1
17	RIGHT DOOR	1.03.68.688	
19	LEFT DOOR	1.03.68.689	
	LEFT DOOR HANDLE	1.02.26.509	
		1.02.26.510	
20	DOOR GASKET	1.02.61.851	
24	LED LIGHT	1.01.08.082	
26	RACKS	1.03.95.10.235	1
34	UNIVERSAL WHEEL	1.02.75.011	
42	COMPRESSOR	6.03.01.369	1
43	CONDENSER	1.03.57.069	1
44	CONDENSER FAN	1.01.11.202	1
45	POWER CORD	1.01.01.252	
48	SENSOR	1.01.13.158	1
49	LEFT HINGE	1.03.79.160	
50	RIGHT HINGE	1.03.79.161	
51	SENSOR WIRE	1.01.13.159	

PRN2101DX



1	CABINET	36	PANEL
2	FRONT PANEL ASSEMBLY	37	WATER DRYER BOX
3	LIGHT BOX STEEL	38	SUPPORT PLATE
4	TOP LED LIGHT	39	STEEL SHELF
5	UPPER HINGE	40	COMPRESSOR COVER
6	SCREW	41	WATER DRYER
7	EVAPORATOR	42	COMPRESSOR
8	EVAPORATOR FAN	43	CONDENSER
9	FAN COVER	44	CONDENSER FAN
10	INSIDE LAMP SWITCH	45	POWER CORD
11	LIGHT BOX SWITCH	46	HOLDER
12	WHITE COVER	47	INNER WIRE
13	CONTROL BOARD WIRE	48	SENSOR
14	LIGHT BOX	49	LEFT HINGE
15	DIGITAL CONTROL BOARD	50	RIGHT HINGE
16	PANEL STICKER	51	SENSOR WIRE
17	RIGHT DOOR		
18	RIGHT DOOR GASKET		
19	LEFT DOOR		
20	LEFT DOOR GASKET		
21	ELECTRICAL BOX		
22	CENTER SILL		
23	BOTTOM COVER		
24	LED LIGHT		
25	RACKS DECORATION		
26	RACKS		
27	LED LIGHT END COVER		
28	DECORATION PANEL		
29	SUPPORTER		
30	STEEL PANEL		
31	WATER PIPE		
32	STEEL PANEL		
33	SUPPORTER		
34	FOOT		
35	PANEL		