

BOM LIST FOR PRF165400XW & PRF167400XB

| NO | PART DESCRIPTION (ENG) |
|----|------------------------------|
| 1 | Can Support(Chute Bar) |
| 2 | Bushing |
| 3 | Shelf Bar |
| 4 | Curve Shelf |
| 5 | Door Gasket |
| 6 | Hinge Cover |
| 7 | Hinge Cover Screw |
| 8 | Upper Hinge(white) |
| 9 | Hinge Screw Assy |
| 10 | Upper Hinge Rubber Washer |
| 11 | Hinge Plug |
| 12 | Thermostat Cover |
| 13 | Thermostat Cover Screw |
| 14 | Thermostat Knob |
| 15 | Defrost Button |
| 16 | Thermostat |
| 17 | Bottom Hinge Rubber Washer |
| 18 | Door Spindle Washer |
| 19 | Bottom Hinge |
| 20 | Adjustable Foot |
| 21 | Foot |
| 22 | Foot Screw |
| 23 | Power Supply Cord |
| 24 | Drip Tray |
| 25 | Wire Clamp Screw |
| 26 | 818 Screw M4×8 (Galvanized) |
| 27 | Half Wire Shelf |
| 28 | Evaporator Door |
| 29 | Evaporator Door Bushing |
| 30 | Compressor Support |
| 31 | Compressor Rubber Washer |
| 32 | Compressor Sleeve |
| 33 | Compressor Screw |
| 34 | Compressor |
| 35 | PTC & OLP Combination |
| 36 | PTC Cover |
| 37 | Filter |
| 38 | Evaporator |
| 39 | Door Assy |
| 40 | Hinge Plug |

