



NO.	PARTS	QTY
1	Door handle	1
2	Door hook	1
3	Door shaft	1
4	Lower door clamp	1
5	knob	2
6	Indicator light cover	1
7	thermostat	1
8	timer	1
9	Bake tray	1
10	Bake wire	1
11	crumb tray handle	1
12	feet	4
13	crumb disc steel wire	1
14	crumb tray	1
15	Heating tube	1
16	Shell	1
17	Back plate	1
18	6n-4 thread buckle	1
19	power cord	1
20	C distance bar	2
21	Inner Tank	1
22	Support plate	1
23	Door hook spring	1
24	door plank	1
25	Knob cover	2
26	Door glass	1
27	Handle trim	1
28	tong	1

Model No: PTO101